

## Proper Installation on DIN Rail

- 1) Slide under flexible latches
- 2) Push to the right and against the DIN rail




End View

Flexible Latches



Back View



Front View